



Steps • Pass 20 Fr dilator over Stiff Wire • Mark anterior (12:00) position • Gently pull back and note rotation clock position change • Device will rotate the same degree in opposite direction



















Conclusion

 Quick, easy, accurate and reproducible way to correct for endograft rotation and help align fenestrations in tortuous anatomy.



